




TRIPLE GANG COMBINATION



Introducing the thinnest switches & sockets wall box to make it "real slim" fit into the in earth Plano Slim Line. Plano Slim Line wall. All articles are supplied as complete encompasses the 21st Century design. Slim unit including the wall box. Plano Slim and modern, it is available in many attractive Line will definitely enhance the appearance colors. Plano Slim Line uses specially designed of your interior homes.

All Plano Slim Line series are available in 4 (four) magnificent colors






Pearl White
























## INTRODUCING THE THINNEST SWITCHES & SOCKETS








For flush mounting 13A 250V~ Article No. E65B WID



SINGLE CHANGE OVER SWITCH



SINGLE CHANGE OVER SWITCH WITH INDICATOR LAMP For flush mounting 10AX 250V~ Article No. E66D WID




THREE POLE SWITCHES WITH INDICATOR LAMP For flush mounting 16AX 400V~ Article No. E66E WID



SINGLE NETWORK SOCKET OUTLET Cat. 5e (RJ 45) For flush mounting (Without claw) Article No. E674 WID



TV CABLE SOCKET OUTLET F TYPE CONNECTOR Screw mounting only (without claw)
Article No. E685 WID




SHAVER SOCKET OUTLET Including external transformer For flush mounting Article No. E650 WID




DO NOT DISTURB INDICATOR For flush mounting 230V~ Article No. E641 WID



For flush mounting 16A 250V~ Article No. E652 WID



SINGLE SWITCH For flush mounting 10AX 250V~ Article No. E661 WID



DOUBLE CHANGE OVER SWITCH For flush mounting 10AX 250V~ Article No. E664 WID



INTERMEDIATE SWITCH For flush mounting 10AX 250V~ Article No. E66G WID



DIMMER FOR INCANDESCENT LAMP WITH PUSH ON PUSH OFF SWITCH For flush mounting 60 - 500W, 220V~ Article No. E691 WID (one way) Article No. E691/2W WID (two way/change over)



DUAL UNIVERSAL NETWORK SOCKET OUTLETS (RJ45/RJ12/RJ11) For flush mounting Article No. E676 WID



ANTENNA SOCKET OUTLET FOR TV AND RADIO SINGLE USE For flush mounting Article No. E681 WID




VOLUME CONTROL For flush mounting 100V 24W Article No. E686 WID



DO NOT DISTURB & MAKE UP ROOM SWITCH For flush mounting 10AX 250V~
Article No. E66L WID/DND-MUR



BRITISH STANDARD SOCKET OUTLET WITH SWITCH, INDICATOR LAMP AND CHILD PROTECTION



DOUBLE SWITCH For flush mounting 10AX 250V~ Article No. E662 WID



SINGLE PUSH BUTTON SWITCH



INTERMEDIATE SWITCH WITH INDICATOR LAMP For flush mounting 10AX 250V~ Article No. E66J WID



MOTION SENSOR SWITCH For flush mounting 500W 220V~ Article No. E695 WID




DUAL UNIVERSAL NETWORK SOCKET OUTLETS CAT.5e (RJ45) For flush mounting Article No. E677 WID



SATELLITE ANTENNA SOCKET OUTLET For flush mounting Article No. E684 WID



DO NOT DISTURB SWITCH For flush mounting 10AX 250V~ Article No. E663 WID/DND



DO NOT DISTURB AND MAKE-UP ROOM INDICATOR For flush mounting 230V~ Article No. E642 WID



For flush mounting 13A 250V~ Article No. E655 WID

BRITISH STANDARD SOCKET OUTLET WITH SWITCH AND CHILD PROTECTION For flush mounting 13A 250V-Article No. E657 WID











ANTENNA SOCKET OUTLET FOR TV ONLY For flush mounting Article No. E683 WID



KEY CARD HOLDER SWITCH For flush mounting 10AX 250V~ Article No. E660 WID (one way) Article No. E660/2W WID (two way/change over)



DOUBLE GANG COMBINATION